Revolutionary Chicken Canning Jar Sprout Rack





Copyright © 2020. Revolutionary Chicken. All rights reserved.

Materials


• 3/8" X 36" square dowels (5): \$.98/each

https://www.homedepot.com/p/Waddell-36-in-x-3-8-in-Hardwood-Square-Dowel-8306U/100534453

- □ 11.25″ (6)
- **1** 5" (4)
- **4**.5″ (4)
- **1**0.5" (2)
- **2**.75" (2)
- Wood glue
- Plastic wrap
- (optional): outdoor polyurethane
- (optional): clamps

Total: \$4.90

Dimensions (in Inches)





Tips

- 1. Since these measurements are fairly small, there is not a lot of room for inaccurate cuts. You may want to test your saw to see how to mark the piece of wood. For example, my miter saw takes off about 1/8" from my measuring point, so I mark 1/8" greater than the measurement I need.
- 2. This wood will get wet, so you may want to apply a few coats of outdoor polyurethane (spray-on works well).
- 3. Use wood glue to attach pieces. For strong joints, clamp all glued pieces together for 30 minutes.
- 4. Start with gluing the center rack. That way you won't need to try to exactly fit "inside" pieces. *See picture.*
- 5. Wrap the base underneath with a few layers of plastic wrap, pushing the wrap down inside the base so it forms a pool. *See picture.*





Sprouting Process

	Morning	Evening
Day 1	 Fill a jar with no more than 1 cup grains or lentils. Add water so that it is higher than the grains by at least two inches. 	 Drain and rinse *Each time you rinse, set jar upside down on rack at an angle.
Day 2	 Rinse jar from day 1 Start seeds in second jar	Drain new jarRinse jar from day 1
Day 3	Rinse day 1 and day 2 jarsStart seeds in third jar	Drain new jarRinse jars from days 1 and 2
Day 4	 Use sprouts from day 1 (move to Fodder System if you are growing fodder) Start that as a new jar Rinse day 2 and 3 jars 	 Drain new jar Rinse jars from days 2 and 3